

DURA-PUMP™ TOP UNLOAD

DP 6000 Series | DEF 2000 Series

Contents:

- A** (1) Dura-Pump™
- B** (1) 1" Dip Tube
- C** (2) 1" Hose Barbs
- D** (1) 1" x 12ft, 3.6m Discharge Hose
- E** (2) 1" Hose Clamps
- F** (1) Ball Valve Nozzle
- G** (1) Dura-Meter™ (optional)
- H** (1) 1" Nipple

Tools Required:

1. 5/16 wrench or flat head screwdriver
2. Pipe thread sealant

See page 1 for finished photo.

ATTENTION

Apply an even coat of Thread Sealant on male threads. Hand tighten joints and torque another 1/2 to 3/4 turn until threads are sealed.

Dip Tube & Discharge Hose

(see illustration 1)

Step 1: Thread **B** into the suction side of **A**


Step 2: Screw **C** into the discharge side of **A**

Step 3: Slide end of **D** onto **C** and tighten **E**

Step 4: Slide the second **C** into opposite end of **D** and tighten **E**

If you have purchased a Dura-Meter™, skip Step 5 and proceed to Step 6.

Step 5: Thread **F** onto end of **C**



(Optional) Dura-Meter™

(see illustration 2)

Step 6: Thread **H** into right "OUT" port of **G**

Step 7: Thread left port of **G** onto **C**

Step 8: Thread **F** onto **H**

